


# Heat Exchanger Interchangability

## Steam to Water *(Use as a guide only - Actual Selection may vary with conditions)*



Steam to Water			
WHEATLEY	B&G	TACO	AMTROL
WS424 (*) A	SU42 (*)	4 (*) 04S	S424 (*) A
WS436 (*) A	SU43 (*)	4 (*) 06S	S436 (*) A
WS448 (*) A	SU44 (*)	4 (*) 08S	S448 (*) A
WS460 (*) A	SU45 (*)	4 (*) 10S	S460 (*) A
WS472 (*) A	SU46 (*)	4 (*) 12S	S472 (*) A
WS484 (*) A	SU47 (*)	4 (*) 14S	S484 (*) A
WS624 (*) A	SU62 (*)	6 (*) 04S	S624 (*) A
WS636 (*) A	SU63 (*)	6 (*) 06S	S636 (*) A
WS648 (*) A	SU64 (*)	6 (*) 08S	S648 (*) A
WS660 (*) A	SU65 (*)	6 (*) 10S	S660 (*) A
WS672 (*) A	SU66 (*)	6 (*) 12S	S672 (*) A
WS684 (*) A	SU67 (*)	6 (*) 14S	S684 (*) A
WS824 (*) A	SU82 (*)	8 (*) 04S	S824 (*) A
WS836 (*) A	SU83 (*)	8 (*) 06S	S836 (*) A
WS848 (*) A	SU84 (*)	8 (*) 08S	S848 (*) A
WS860 (*) A	SU85 (*)	8 (*) 10S	S860 (*) A
WS872 (*) A	SU86 (*)	8 (*) 12S	S872 (*) A
WS884 (*) A	SU87 (*)	8 (*) 14S	S884 (*) A
WS896 (*) A	SU88 (*)	8 (*) 16S	S896 (*) A
WS1036 (*) A	SU103 (*)	10 (*) 06S	S1036 (*) A
WS1048 (*) A	SU104 (*)	10 (*) 08S	S1048 (*) A
WS1060 (*) A	SU105 (*)	10 (*) 10S	S1060 (*) A
WS1072 (*) A	SU106 (*)	10 (*) 12S	S1072 (*) A
WS1084 (*) A	SU107 (*)	10 (*) 14S	S1084 (*) A
WS1096 (*) A	SU108 (*)	10 (*) 16S	S1096 (*) A
WS10108 (*) A	SU109 (*)	10 (*) 18S	S10108 (*) A
WS10120 (*) A	SU1010 (*)	10 (*) 20S	S10120 (*) A

(\*) Insert number of tube passes

Steam to Water			
WHEATLEY	B&G	TACO	AMTROL
WS1236 (*) A	SU123 (*)	12 (*) 06S	S1236 (*) A
WS1248 (*) A	SU124 (*)	12 (*) 08S	S1248 (*) A
WS1260 (*) A	SU125 (*)	12 (*) 10S	S1260 (*) A
WS1272 (*) A	SU126 (*)	12 (*) 12S	S1272 (*) A
WS1284 (*) A	SU127 (*)	12 (*) 14S	S1284 (*) A
WS1296 (*) A	SU128 (*)	12 (*) 16S	S1296 (*) A
WS12108 (*) A	SU129 (*)	12 (*) 18S	S12108 (*) A
WS12120 (*) A	SU1210 (*)	12 (*) 20S	S12120 (*) A
WS1436 (*) A	SU143 (*)	14 (*) 06S	S1436 (*) A
WS1448 (*) A	SU144 (*)	14 (*) 08S	S1448 (*) A
WS1460 (*) A	SU145 (*)	14 (*) 10S	S1460 (*) A
WS1472 (*) A	SU146 (*)	14 (*) 12S	S1472 (*) A
WS1484 (*) A	SU147 (*)	14 (*) 14S	S1484 (*) A
WS1496 (*) A	SU148 (*)	14 (*) 16S	S1496 (*) A
WS14108 (*) A	SU149 (*)	14 (*) 18S	S14108 (*) A
WS14120 (*) A	SU1410 (*)	14 (*) 20S	S14120 (*) A
WS1636 (*) A	SU163 (*)	16 (*) 06S	S1636 (*) A
WS1648 (*) A	SU164 (*)	16 (*) 08S	S1648 (*) A
WS1660 (*) A	SU165 (*)	16 (*) 10S	S1660 (*) A
WS1672 (*) A	SU166 (*)	16 (*) 12S	S1672 (*) A
WS1684 (*) A	SU167 (*)	16 (*) 14S	S1684 (*) A
WS1696 (*) A	SU168 (*)	16 (*) 16S	S1696 (*) A
WS16108 (*) A	SU169 (*)	16 (*) 18S	S16108 (*) A
WS16120 (*) A	SU1610 (*)	16 (*) 20S	S16120 (*) A
WS1836 (*) A	SU183 (*)	18 (*) 06S	S1836 (*) A
WS1848 (*) A	SU184 (*)	18 (*) 08S	S1848 (*) A
WS1860 (*) A	SU185 (*)	18(*) 10S	S1860 (*) A
WS1872 (*) A	SU186 (*)	18(*) 12S	S1872 (*) A
WS1884 (*) A	SU187 (*)	18(*) 14S	S1884 (*) A
WS1896 (*) A	SU188 (*)	18(*) 16S	S1896 (*) A
WS18108 (*) A	SU189 (*)	18(*) 18S	S18108 (*) A
WS18120 (*) A	SU1810 (*)	18(*) 20S	S18120 (*) A
WS2036 (*) A	SU203 (*)	20(*) 06S	S2036 (*) A
WS2048 (*) A	SU204 (*)	20(*) 08S	S2048 (*) A
WS2060 (*) A	SU205 (*)	20(*) 10S	S2060 (*) A
WS2072 (*) A	SU206 (*)	20(*) 12S	S2072 (*) A
WS2084 (*) A	SU207 (*)	20(*) 14S	S2084 (*) A
WS2096 (*) A	SU208(*)	20(*) 16S	S2096 (*) A
WS20108 (*) A	SU209 (*)	20(*) 18S	S20108 (*) A
WS20120 (*) A	SU2010 (*)	20(*) 20S	S20120 (*) A

(\*) Insert Number of tube passes